


New ANSI and EN 388 Cut Glove Standard

DIFFERENCE BETWEEN STANDARDS


The ANSI cut standard uses a razor blade in its testing method to determine the weight in grams needed to cut through the material of the glove using linear motion. A cut level is then assigned to the gloves material, determined by the range of weight used during testing.



_ _____


CONDUCTIVE STRIP TO DETECT CUT THROUGH

The EN 388 cut standard uses a circular blade, under a fixed load, in its testing method to determine the blade rotations needed to cut through the material of the glove. A cut level is then assigned to the gloves material, determined by the number of blade rotations used during testing. Additionally, a cut test using a TDM 100 cut test machine is also performed. This test, measured in Newtons, will measure the cut resistance with a straight blade. This will add an additional 6 levels to the cut rate standard, which are represented by letters A to F.



CONDUCTIVE STRIP TO DETECT CUT THROUGH

NEW ANSI STANDARDS



EN 388 LEVELS

Cut Level	Weight (G) Needed to cut with 1" (25mm) blade travel	Average cut index (10 measurements)
0	< 119	< 1.2
1	120 - 249	1.2 - 2.4
2	250 - 499	2.5 - 4.9
3	500 - 999	5.0 - 9.9
4	1000 - 1999	10.0 - 19.9
5	> 2000	> 20



2 Newtons (203 grams)

5 Newtons

(509 grams)

10 Newtons

(1019 grams)



15 Newtons (1529 grams)



22 Newtons (2243 grams)



30+ Newtons (3059 grams)

